


SVIVE®

TRITON 70%

MECHANICAL GAMING
KEYBOARD

Imported by Svive, Østre Kullerød 4
N-3241 Sandefjord, Norway | svive.gg



Dual System Support

Fn+A Switching to Windows OS Mode. (Please refer to the table below for functions)

Fn+S Switching to Mac OS Mode. (Please refer to the table below for functions)

	Win OS	Mac OS		Win OS	Mac OS
Fn+1	F1	☀	Fn+7	F7	⏮
Fn+2	F2	☀	Fn+8	F8	⏭
Fn+3	F3	☐	Fn+9	F9	⏭
Fn+4	F4	☐	Fn+10	F10	⏮
Fn+5	F5	☐	Fn+11	F11	⏮
Fn+6	F6	☐	Fn+12	F12	⏮

Fn+Ctrl(Left)	F1-F12 & number switch
Fn+S	Win mode
Fn+A	Mac mode
Fn+P	Bluetooth set
Fn+Win	Lock win key
Fn+Home	Backlight set.
Fn+Insert	Sidelights set.
Fn+z/x/c	3 macro key set
Fn+Tab	Office/Game switch

Fn+Ctrl(Left): F1-12 & Number function switching

Backlight Setting

FN+HOME Cyclic switching of 17 backlighting effects

FN+INS Sidelight effect cycle switching, support off

FN+END Backlight color switching

Fn+↑ Increase backlight brightness

Fn+↓ Decrease backlight brightness

Fn+← Increase backlight speed

Fn+→ Decrease backlight speed

Introduction

Slive Triton 70% is your key to successful gaming, Slive Gaming has designed the ultimate Nordic gaming keyboard for an even better gaming experience. Take full control of your opponents with precise mechanical switches that won't let you down. Your new Triton RGB keyboard connects easily and takes you to the next level without lag. Triton 70% is a mechanical RGB keyboard with 71 keys. Offering two-color keycaps, RGB backlight, control of hardware backlight, and FN multi-function key combination.



Product size	330x102x37mm±2mm
Keyboard standard	71 key mechanical keyboard
Backlight	RGB
Keyboard Material	Metal + ABS
Keycap	PBS Two-color injection
Axial	Blue/Red/Brown/Speed
Working voltage	5V

Packaging content
1x Mechanical Keyboard
1x Keycap puller tool
8x Extra keycap set
1x User manual
System support
Windows XP / Vista / 7 / 8 / 10, IOS, MacOS, Linux, Android

GAME MODE SET (MACRO KEY SET)

Fn+Tab: office/Gameswitch The keyboard backlight flashes multiple times during the switch, and the key macro recording takes effect only in the game mode.

Fn+Z/X/C (Press 3 secs): Set macro key

Fn+Z/X/C (Click): Turn on/off the corresponding macro key

MACRO KEY SET METHOD

1. **Fn + Tab** switch to game mode; the keyboard backlight flashes multiple times during switching.

2. **Fn+Z/ X/C** (press 3 secs) Select a group of macro keys (such as Fn+ Z). At this time, the Caps and Win keys will continue to flash, indicating that macro recording has been entered. (If there is no response, the game mode is not loading correctly; please repeat step 1)

3. Click to set the sequence of keys to be triggered (up to 32 combos possible).

4. **Fn + Z (press 3 secs)**, save. At this time, the Caps and Win keys will stop flashing.

MACRO BUTTON USE

1. **Fn+Tab** Switch to game mode, the keyboard backlight flashes multiple times during switching.

2. **Z/ X/C:** Click to trigger the corresponding macro button function. (If there is no response, the game mode is not loading correctly, please repeat step 1)

Tip: Please set the macro key before using it.

Other Settings

Fn +Space(press 3 secs):Reset

Fn +Win :Lock/unlock Windows key